

ANEST IWATA Europe S.r.I. 46. Corso Vigevano 10155. Torino Italy Direct Tel +39 011 - 24 80 868 Fax +39 011 - 22 74 406 info@anest-iwataeu.com www.anest-iwataeu.com



ANEST IWATA Italia S r I

46, Corso Vigevano 10155, Torino (Italy) Tel. diretto +39 011 - 24 80 868 - Fax +39 011 - 85 19 44 info@anest-iwataeu.com

www.anest-iwata.it

ANEST IWATA Europe S.r.I.

SUCURSAL ESPAÑA Y PORTUGAL Avda.del Maresme, 44-46 / 08918 - Badalona Barcelona Móvil. +34 637 370 293 info@anest-iwata.es

ANEST IWATA Europe S.r.I.

NIEDERI ASSUNG DEUTSCHI AND Dorfäckerstr 25 74248 Ellhofen Telefon: +49 (0)7134- 917368 - Fax: +49 (0)7134 - 917378 Handy: +49 (0)172 - 62 74 542 f.e.anest-iwata@t-online.de www.anest-iwata.de ANEST IWATA U.K. Ltd. Unit 2. Cedar Trade Park.

info@anest-iwata.se

ANEST IWATA France S.A.

Ferndown Industrial Estate Wimborne, Dorset - BH21 7SB U.K.

ANEST IWATA Scandinavia AB.

Ögärdesvägen 6C, 433 30 PARTILLE

Tel. +46 (0)31 - 340 28 60 - Fax +46 (0)31 - 340 28 69

25 rue de Madrid - BP 7405 38074 St Quentin Fallavier

Tél. +33 (0)4 - 74 94 59 69 - Fax +33 (0)4 - 74 94 34 39

Tel. +44 (0)1202 - 89 59 99 - Fax: +44 (0)1202 - 89 56 66

enquiries@anest-iwata.co.uk www.anest-iwata.co.uk

European Sales Branches:

www.anest-iwata.se

www.anest-iwata.fr

Instruction Manual

NEW 77 SPRAY GUN



Before use, adjustment or maintenance, it is important to read this instruction manual very) carefully. This manual must be stored in a safe place for any future reference that may be necessary.

This ANEST IWATA spray guns kit complies to ATEX regulations 94/9/EC, protection level: II 2 G X Suitable for using Zones 1 and 2.

X marking: Any static electricity discharge from the spray gun is to be diverted to the ground via the conductive air hose as a stipulated.

IMPORTANT

This spray oun should be operated only by an adequately trained operator, for safe use and maintenance of the equipment, Any misuse or handling other than those indicated in this Instruction Manual is not covered by guarantee. ANEST IWATA disclaims all responsibility for any accident or damage caused by failure to observe the operational and safety procedures as from this manual. In the interest of user friendliness, this manual contains information in a brief and concise form.

For any additional information you may require regarding spray guns operations, or if any missing parts or any damage during transportation is found, please contact your nearest ANEST IWATA Company (see last cover page).

Be sure to observe warnings and cautions in this instruction manual.

If not, it can cause paint ejection and serious bodily injury by drawing organic solvent.

Be sure to observe following \wedge marked items which are especially important.

	- 2:3
⚠ WARNING	Indicates a potentially hazardous situation which, if not avoided, may result in serious injury or loss of life.
⚠ CAUTION	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or property damage.
IMPORTANT	Indicates notes which we ask you to observe. The safety precautions in this instruction manual are the minimum necessary conditions. Follow national and local regulations regarding fire prevention, electricity and safety as well as your own company regulations.

IMPORTANT SPECIFICATIONS

Max. Pressure:	6.8 bar (98 PSI)	Max. Temperature:	
Noise Level (LAeqT)	82.1 dB (A)	Atmosphere	5 ~ 40 °C
Spray conditions	Recommended	Air and fluid	5 ~ 43 °C
Measuring point	1m backwards from gun, 1,6 m height	Air connection:	G 1/4"
	-	Fluid connection:	G 3/8"

TECHNICAL SPECIFICATIONS

Model	Fluid nozzle Orifice Size mm (in)	Atomizing Air pressure bar (psi)	Air Consumption I/min (cfm)	Fluid Output ml/min.	Pattern Width mm (in)	Air cap Mark	Mass g (lbs)
NEW 77 Pressure feed							
NEW 77 0	1.2 (0.047)		430 (15.2)	480	445 (17.4)	0	
NEW 77 Suction feed							
NEW 77 1S	1.5 (0.059)		185 (6.3)	255	210 (8.2)	1	
NEW 77 2S	2.0 (0.079)		250 (8.8)	345	255 (10.0)	2	550
NEW 77 3S	2.5 (0.098)	3.5 (50)	325 (11.5)	435	280 (11.0)	3	
NEW 77 Gravity feed							(1.22)
NEW 77 1G	1.5 (0.059)		185 (6.3)	285	230 (9.0)	1	
NEW 77 2G	2.0 (0.079)		250 (8.8)	390	290 (11.3)	2	
NEW 77 3G	2.5 (0.098)		325 (11.5)	485	330 (12.9)	3	

ANEST IWATA Corporation 3176, Shinyoshida-cho, Kohoku-ku, Yokohama, 223-8501 Japan

^{*1} Atomizing air pressure means air pressure at gun inlet when trigger is pulled and air flows. Manufactured by:

SAFETY WARNINGS



FIRE OR EXPLOSION HAZARD

1. Spark and open flames are strictly prohibited.

Paints can be highly flammable and can cause fire.

Avoid any ignition sources such as smoking, open flames, electrical goods, etc.





2. Never use the following HALGOGENATED HYDROCARBON SOLVENTS

which can cause cracks or dissolution on gun body (aluminum) by chemical reaction.

- Unsuitable solvents methyl chloride, dichloromethane, 1.2-dichloroethane,carbon tetrachloride, trichloroethylene, 1.1.1-trichloroethane
- Be sure that all fluids and solvents are compatible with gun parts.

We are ready to supply a material list used in the product.

3. Securely ground spray gun by using air hose with built-in ground wire.

Ground wire: Less than $1M\Omega$ Check the earth stability periodically.

If not, insufficient grounding can cause fire and explosion due to static electric sparking.



IMPROPER USE OF EQUIPMENT

1. Never point gun towards people or animals.

If done, it can cause inflammation of eyes and skin or bodily injury.

2. Never exceed maximum operating pressure and maximum operating Temperature.



If not, remaining pressure can cause bodily injury due to improper operation or scattering of cleaning liquid. In order to release pressure, first stop supply of compressed air, fluid and thinner to spray gun. Then remove fluid adj. knob and pull fluid needle set towards you.



4. Tip of fluid needle set has a sharp point.

Do not touch the tip of fluid needle during maintenance for the protection of the human body.



PROTECTION OF HUMAN BODY

1. Use in a well-ventilated site by using spray booth.

If not, poor ventilation can cause organic solvent poisoning and catch fire.

2. Always wear protective gear safety glasses, mask, gloves.

If not, cleaning liquid, etc., can cause inflammation of eyes and skin.

If you feel something wrong with eyes or skin, immediately see a doctor.







3. Wear earplugs if necessary.

Noise level can exceed 85 dB(A), depending on operating conditions and painting site

4. If operators pull the trigger many times during operation, it may cause carpal tunnel syndrome. Be sure to take a rest if you feel tired.



OTHER PRECAUTIONS


1. Never alter this spray gun.

If done, it can cause insufficient performance and failure.


2. Enter working areas of other equipment (robots, reciprocators, etc.) after machines are turned off. If not, contact with them can cause injury.

★ ANEST IWATA

COMMENTS



SPARE PARTS LIST



SPARE PARTS LIST

DESCRIPTION	REF.PART
AIR CAP SET	1
FLUID NOZZLE	2 •
FLUID NOZZLE PACKING SET	3 •
FLUID NEEDLE PACKING	3-1/ 3-2
NEEDLE PACKING NUT	4
SPREAD ADJ. VALVE SET	5
O RING	5-1 ●
STOPPER	5-2
GASKET	6
FLUID NEEDLE GUIDE	7
FLUID ADJ. KNOB	8
FLUID NEEDLE SPRING	9
FLUID NEEDLE SET	10 •
O RING	11
GUN BODY	12
AIR NIPPLE	13
AIR ADJ. VALVE SET	14
STOP RING	15
TRIGGER STUD	16
TRIGGER	17
AIR VALVE SPRING	18
AIR VALVE	19 •
AIR VALVE SEAT SET	20
FLUID NIPPLE	21
SPANNER	22
BRUSH	23

FLUID NOZZLE-FLUID NEEDLE SET COMBINATION

Fluid noz	Fluid needle set						
Orifice	Mark	Mark					
mm(in)							
1.2 (0.047)	0	0					
1.5 (0.059)	1	1					
2.0 (0.079)	2	2					
2.5 (0.98)	3	3					

Marked parts wearable parts.

NOTE: When ordering parts, specify gun's model, part name with ref.No. and marked No.of air cap set, fluid nozzle and fluid needle. When replacing fluid nozzle or/and fluid needle for pressure feed application, please order nozzle needle set.



OTHER PRECAUTIONS

3. Never spray foods or chemicals through this gun.

If done, it can cause accident by corrosion of fluid passages or adversely affect health by mixed foreign matter.

4. If something goes wrong, immediately stop operation and find the cause. Do not use again until you have solved the problem.

HOW TO CONNECT



CAUTION

- Use clean air filtered through air dryer and air filter. If not, dirty air can cause painting failure.
- When you use this gun for the first time after purchasing, adjust fluid needle packing set.
 Slowly tighten fluid packing seat and loosen a bit when fluid needle set does not return smoothly, and adjust so that fluid needle set smoothly moves.
- When you use this gun for the first time after purchasing, clean fluid passages spraying thinner and remove rust preventive oil.
 If not, remaining preventive oil can cause painting failure such as fish eyes.
- Firmly fix hose or container to spray gun. If not, disconnection of hose and drop of container
- Firmly fix hose or container to spray gun. If not, disconnection of hose and drop of containe can cause bodily injury.
- 1. Connect an air hose to air nipple tightly.
- 2. Connect a fluid hose or a container to fluid nipple tightly.
- 3. Flush the gun fluid passage with a compatible solvent.
- 4. Pour paint into container, test spray and adjust fluid output as well as pattern width

HOW TO OPERATE

Suggested air pressure is 3.5 bar (50 PSI)

Recommended paint viscosity differs according to paint property and painting conditions. 15 to 23 sec. / Ford cup#4 is recommendable.

Keep fluid output as small as possible to the extent that the job will not be hindered. It will lead to better finishing with fine atomization.

Set the spray distance from the gun to the work piece as near as

possible within the range of 200-250 mm (8-10 in).

200-250 mm 8-10 in

he cun should be held so that it is perpendicular to the surface of the workniese at all times. Then, the cun

The gun should be held so that it is perpendicular to the surface of the workpiece at all times. Then, the gun should move in a straight and horizontal line. Arcing the gun causes uneven painting.

MAINTENANCE AND INSPECTION



WARNING

First release air and pressure fully according to item No. 3 of "Improper use of equipment" of WARNING on page 2.

- Tip of fluid needle set has a sharp point. Do not touch the tip of needle valve during maintenance for protection of the human body.
- Be careful not to damage the tip of the fluid nozzle or put your hand on it.
- Only an experienced person who is fully conversant with the equipment can do maintenance and inspection.

CAUTION



- Never use commercial or other parts instead of ANEST IWATA original spare parts.
- Never immerse the whole gun into liquid such as thinner.
- Never damage holes of air cap fluid nozzle or fluid needle.

Step-by-step procedure	Important
Pour remaining paint to another container. Clean fluid passages and air cap set. Spray a small amount of thinner to clean fluid passages.	Incomplete cleaning can fail pattern shape and uniform particles. Especially clean fully and promptly after use with two-component paint.
2.Clean each section with brush soaked with thinner and wipe out with waste cloth.	Do not immerse the whole gun in thinner. If done, it can damage parts. When cleaning, never scratch any holes of air cap set and fluid nozzle, and fluid needle set.
3. Before disassembly, fully clean fluid passages. (1) Disassemble fluid nozzle. Use ring spanner, box wrench or optional exclusive spanner, to disassemble fluid nozzle. (2) Disassemble fluid needle set. Remove fluid adj. knob and pull out fluid needle set from gun body. Pay attention so that spring does not suddenly fly out since fluid adj. knob is strongly pushed by fluid needle spring and piston spring.	3. During disassembly, do not scratch seat section. (1) Remove fluid nozzle after removing fluid needle set or while keeping fluid needle pulled, in order to protect seat section. (2)Pull fluid needle set after loosening fluid needle packing set to protect fluid needle packing set. Be careful when handling tip of fluid needle set since it is sharp.
4.To adjust fluid needle packing set, while keeping fluid needle set inserted, tighten fluid needle packing seat by hand and then tighten further by spanner. When replacing fluid needle packing set, be careful that the top old packing does not remain inside	4.Too much tightening of fluid needle packing set can cause bad movement of fluid needle set and fluid leakage from the tip of fluid needle set.
6.Turn pattern adj. knob or air adj. knob counterclockwise to fully open. And then tighten pattern adj set or air adj. set.	If pattern adj.Knob or air adj. Knob are not fully opened, tip of it can contact and damage fluid nozzle and cause seizure of thread.
Where to inspect	Parts replacement standard
Each hole passage of air cap and fluid nozzle	Replace if it is crushed or deformed.
2. Packing and O ring	Replace if it is deformed or worn out.
3.Leakage from seat section between fluid nozzle and fluid needle set	Replace them if leakage does not stop after fully cleaning fluid nozzle and fluid needle set. If you replace fluid nozzle or fluid needle set only, fully match them and confirm that there is no leakage.

TROUBLESHOOTING

Spray Pattern		Problems	Remedies
Spray ration	Fluttering	Air enters between fluid nozzle and tapered seat of gun body. Air is drawn from fluid needle packing set 3. Air enters fluid container fitting nut or fluid hose joint.	1. Remove fluid nozzle to clean seat. If it is damaged, replace nozzle. 2. Tighten fluid needle packing. 3. Fully tighten joint section.
	Crescent	Paint buildup on air cap partially clogs horn holes. Air pressure from both horns differs.	Remove obstructions from horn holes with attached brush. But do not use metal objects to clean horn holes.
	Inclined	Paint buildup or damage on fluid nozzle circumference and air cap center. Fluid nozzle is not properly fitted.	Remove obstructions. Replace if damaged. Remove fluid nozzle, clean seated section
	Split	Paint viscosity too low. Fluid output too high.	Add paint to increase viscosity. Tighten fluid adj. knob to reduce fluid output or turn pattern adj. knob clockwise.
	Heavy Center	Paint viscosity is too high. Fluid output is too low.	Add thinner to reduce viscosity. Turn fluid adj. knob counter-clockwise to increase fluid output.
	Spit	Fluid nozzle and fluid needle set are not seated properly. The first-stage travel of trigger (when only air discharges) decreases. Paint buildup inside air cap set.	Clean or replace fluid nozzle and fluid needle set. Replace fluid nozzle and fluid needle set. Clean air cap set.

PROBLEMS AND REMEDIES

Problem	Where it occurred	Parts to be checked	Cause	Retighten	Adjust	Remedy Clean	Replace
Air leaks (from tip	Air valve set	Air valve	*Dirt or damage on seat			х	x
of air cap)		Air valve seat set	*Dirt or damage on seat			Х	х
			*Wear on air valve spring				х
		O ring	*Damaged or deteriorated				х
Paint leaks	Fluid nozzle	Fluid nozzle - fluid needle set	*Dirt, damage, wear on seat			х	x
			*Loose fluid needle adj. knob		x		
			*Wear on needle spring				х
		Fluid nozzle - gun body	*Insufficient tightening	х			
			*Dirt or damage on seat			Х	х
		Fluid needle - packing set	*Needle does not return due to packing set too tight		х		х
			*Needle does not return due to paint buildup on fluid needle		х	х	
	Fluid needle	Needle packing set - needle set	*Wear	х			х
		Packing seat	*Insufficient tightening	х			
Paint does not flow	Tip of gun	Fluid adj. knob	*Insufficient opening		х		
IIOW		Tip hole of nozzle	*Clogged			Х	
		Paint filter	*Clogged			Х	х

4