


۲

FMT100 Classic Trestle Product Information Guide



T: +44 (0)1582 661993 F: +44 (0)1582 667100 F: sales@fastmovertoolsuk.com

FMT100

Parts & Instructions

Operating Instructions

Technical Specification

SWL:	160kg
Width:	1000mm

Safe Usage

- 1 Build up the Trestle ensuring all the fixings are tight.
- 2 Check that the hook (FMT100/HK) is running parallel to the ground when the trestle is open (*see image*). This will prevent the chain from slipping off the trestle and collapsing.




- 3 Always use the FMT100 Classic Trestle on a level surface. Don't attempt to use it if the trestle is rocking or in anyway unstable.
- 4 The FMT100 Classic Trestle has a load rating of 160kg provided both chains are hooked up correctly. ALWAYS MAKE SURE BOTH CHAINS ARE HOOKED UP BEFORE USE.
- 5 The FMT100 Classic Trestle is designed for vehicle panel preparation and spraying. Do not attempt to sit on it or use it as a standing platform. MISUSE OF ANY TOOL OR STAND COULD LEAD TO SERIOUS INJURY AND DEATH.
- 6 Always wear relevant PPE in accordance with HSE guidelines and your own Health and Safety policy.

Fast Mover Tools T: +44 (0)1582 661993 F: +44 (0)1582 667100 E: sales@fastmovertoolsuk.com www.fastmovertoolsuk.com

FMT100

Parts & Instructions



Parts Diagram

<u>Ref</u>	<u>Q'ty</u>	<u>Code</u>		Description
1	2	FMT100/1		1mtr Foam
2	2	FMT100/2		Inner Base
3	2	FMT100/2A		Outer Base
4	4	FMT100/3		Upright/Leg
	1	Fixing Kit, containing;		
5		8	M8x35 S	et Screw
6		2	M8x50 S	et Screw
7		10	M8 Nylo	С
8		10	M8 Washer	
9		8	25x50 Plastic Bung	
10	2	FMT100/6		780mm Chain
11	2	FMT100/HK		Chain Hook
-	1	Product Information Guide		

Fast Mover Tools T: +44 (0)1582 661993 F: +44 (0)1582 667100 E: sales@fastmovertoolsuk.com www.fastmovertoolsuk.com

Diagram & Parts List

FMT100_Product Instructions 20/09/2012 11:57 Page

FMT100

Parts & Instructions

